


Carvin Amplifiers - Footswitch Reference sheet

MARCH 2015

FS44M: Legacy3, and V3 (100w, WITH Reverb)

momentary switches

(has "MIDI" plug, but NOT for MIDI)




FS44L-V3M: V3M

*CH.3 overrides 1/2 when ON

(same insides as FS44L)


(has "MIDI" plug, but NOT for MIDI)



FS44L: X100B

(same insides as FS44L-V3M)

(has "MIDI" plug, but NOT for MIDI)



FS44: SX300, and older NON-Reverb V3's and V3L's (manufactured before Jan 1, 2012)

(has "MIDI" plug, but NOT for MIDI)




FS33: (not shown, 3-button) Legacy 2 only. Unique circuit using a resistor network. Generic replacements will not work.

FS22:

VT50, Nomad, Belair, (Channel, Reverb)

AG200/AG300, AG100, and mixers (FX on/off).

Used for additional/alternate functions on V3, V3m, Legacy3, X100B(2008+).



2 simple latching switches with a 1/4" TRS plug, make the FS22 compatible with many non-Carvin products.

product	"Select"	"Reverb/Effects"
VT50/Nom./Bel.	Channel (1/2)	Reverb(on/off)
AG300/200/100	DspEff 1 (off/on)	DspEff 2 (off/on)
most Mixers	DspEff 1 (off/on)	DspEff 2 (off/on)
V3 (add'l)	Loop1 (on/off)	Loop2 (on/off)
V3m (alt.)	CH.3 (on/off)*	(Ch.1 / Ch.2)
Legacy3 (alt.)	Channel (1/2)	Reverb(on/off)
X100B (alt.)	Channel (1/2)	Reverb(on/off)
Legacy(1)	Channel (1/2)	Reverb(on/off)
MTS3200	Channel (1/2)	Reverb(on/off)
SX amps(2002+)	Channel (1/2)	Reverb(on/off)
TN100 preamp	preset (UP)	preset (DOWN)
XP2/XP4	DspEff 1 (off/on)	DspEff 2 (off/on)
FX2	DspEff 1 (off/on)	DspEff 2 (off/on)

*CH.3 overrides when ON (functions like Legacy 1)

Legacy(1)	Channel (1/2)	Reverb(on/off)	no longer made
MTS3200	Channel (1/2)	Reverb(on/off)	no longer made
SX amps(2002+)	Channel (1/2)	Reverb(on/off)	no longer made (2 ch. amps)
TN100 preamp	preset (UP)	preset (DOWN)	no longer made
XP2/XP4	DspEff 1 (off/on)	DspEff 2 (off/on)	no longer made
FX2	DspEff 1 (off/on)	DspEff 2 (off/on)	no longer made